

Load Vest

The whole vest is simplified, with a thinner chest plate and a single knob to adjust its height. The slots of the vest allow the load arm to be inserted easily.

Single Arm

The structural design of the Single-Arm steadycam features 14 high precision bearings, design based on human hand simulation that allows for more flexible operation.



VEST+ARM